



## Ordering Informations Commercial Reference

Commercial reference	Description	Ordering information
SenS 1920 M-ST	Cameralink Full-HD Camera SDR26 & HR10-10R connector	9SEC2101AE31MC0# # : <b>product revision</b>
SenS 1920 L-ST	Cameralink Full-HD Camera LSHM130 Connector	9SEC2101AE31LC0# # : <b>product revision</b>

### Included Accessories

- Power and trigger Cable (Hirose HR10 connector)
- 12V power supply
- Heatsinks (M-ST version only)
- Cardboard shipping and storage box

### Optional Accessories

- Optical Filter mount
- Hardened protective case

### Custom variants (OEM)

Various options may be available depending on your camera model:

- Open frame housing
- Sensor without cover glass
- Flex configuration (sensor board split from camera electronics)
- ...

For any specific requirements contact your sales representative or [support@new-imaging-technologies.com](mailto:support@new-imaging-technologies.com)




## FUNCTIONALITIES

### Camera


Main camera features (For full documentation contact [support@new-imaging-technologies.com](mailto:support@new-imaging-technologies.com)):

<b>Sensor characteristics</b>	Sensor type	InGaAs (0.9-1.7 spectral response, see <a href="#">QE curve</a> )
	Pixel pitch	8 $\mu$ m
	Resolution	1920x1080
	Sensor noise	<ul style="list-style-type: none"> <li>• High gain (CDS): 25e<sup>-</sup> typical</li> <li>• Low gain : 150e<sup>-</sup></li> </ul>
	Dynamic range	<ul style="list-style-type: none"> <li>• High gain (CDS): 54dB typical</li> <li>• Low gain: 63dB typical</li> </ul>
	Peak QE	>80%
<b>Camera features</b>	Frame rate	60Hz (12 bit output mode), 37Hz (14 bit output mode)
	Sensor Readout	Global shutter ITR (Integrate Then Read)
	Sensor modes	Low Gain / High gain (CDS)
	Output Type	14 bits with 1X_1Y tap geometry (1 tap) 12 bit with 1X2_1Y tap geometry (2 tap)
	Exposure time	Minimum Integration time: 10 $\mu$ s (Linear) Controlled by camera register or Trigger width
	Trigger	Internal/External (LVTTTL) Software Trigger
	Trigger delay	User-Selectable
	Partial reading mode	Region of Interest (ROI). User-Selectable with a step of 8 pixels. Maximum FPS increase with reduced ROI
<b>Environment and mechanical characteristics</b>	Power consumption (12V supply)	<ul style="list-style-type: none"> <li>• Camera: &lt;5.5W</li> <li>• Cooling: User-Selectable TEC power limit               <ul style="list-style-type: none"> <li>○ Off</li> <li>○ Low : &lt;1W</li> <li>○ Medium : &lt;2W</li> <li>○ High : &lt;4W (Default, user defined value)</li> </ul> </li> </ul>
	Supply voltage range	6 to 15V (Overvoltage, reverse polarity protection).
	Storage temperature	-40 to +80°C
	Operating temperature	-40 to +71°C
	Size (WxHxL, mm)	58x58x71.8 (M-ST) / 52.8 (L-ST) 118x46x65.4 (M-ST) with heatsinks
	Weight	<350g without accessor heatsinks.
	Lens mount	C-Mount
<b>Software (Processing on host system)</b>	Control protocol	Serial NITCam protocol
	NIT Software	NITVision GUI (Windows/Linux, x64/aarch64 platforms) <b><u>! \ Compatible with Dalsa framegrabber only. Tested with XTium/XTium 2 series.</u></b> NITLibrary SDK (Windows/Linux, x64/aarch64 platform, C++/Python language)
	AGC (Histogram Stretching)	Automatic/Manual. Automatic: continuous offset and gain adjustment based on current image histogram
	NUC correction	Correction 1-Point or 2-Point. 2 Point factory calibrated. (20°C sensor Temperature)
	Bad pixel correction	Factory calibrated Bad Pixel Map
	Temperature monitoring	Image Sensor
	Image Flip	Horizontal/Vertical
	Video recording	

QE Curve (typical)



### Electrical ICD (L-ST – LSHM130 output)



- LSHM-130-06.0-X-DV-A-S Pinout


Pin Number	Name	Type	Comment	Pin Number	Name	Type	Comment
1	GND	Power	Supply voltage ground	31	NC		
2	GND	Power	Supply voltage ground	32	NC		
3	CamLinkPair4+	Clock		33	NC		
4	CamLinkPair5+	Data3		34	Trigger Out	TTL	Programmable
5	CamLinkPair4-	Clock		35	NC		
6	CamLinkPair5-	Data3		36	Trigger Out	TTL	Programmable
7	GND			37	NC		
8	GND			38	Trigger In/Out	TTL	Programmable
9	CamLinkPair3+	Data2		39	GND		
10	CamLinkPair2+	Data1		40	GND		
11	CamLinkPair3-	Data2		41	NC		
12	CamLinkPair2-	Data1		42	NC		
13	GND			43	NC		
14	GND			44	NC		
15	CamLinkPair1+	Data0		45	Cable detect		100 Ohm to GND
16	NC			46	NC		
17	CamLinkPair1-	Data0		47	Enable		On : 1.6 to 3.3V or floating Off: Connect to GND to turn off
18	NC			48	NC		
19	GND			49	GND		
20	GND			50	GND		
21	CamLinkPair7+	SerTG		51	GND		
22	CamLinkPair8+	CC1		52	GND		
23	CamLinkPair7-	SerTG		53	GND		
24	CamLinkPair8-	CC1		54	GND		
25	CamLinkPair6+	SerTC		55	Power Input	Power	9 to 35V
26	CamLinkPair9+	CC2		56	Power Input	Power	9 to 35V
27	CamLinkPair6-	SerTC		57	Power Input	Power	9 to 35V
28	CamLinkPair9-	CC2		58	Power Input	Power	9 to 35V
29	GND			59	Power Input	Power	9 to 35V
30	GND			60	Power Input	Power	9 to 35V

\*Products and specifications discussed herein are for evaluation and reference purposes only and are subject to change by NIT without notice. Products are only warranted by NIT to meet NIT's production data sheet specifications.

### Electrical ICD (M-ST – SDR26 video output)

Reference	Designation	Manufacturer
HR10-10R-12SA	Connector Female 12 positions	Hirose

#### Power Supply & Trigger (HR10-10R-12SA73)




#### Video & Communication (MiniCamlink)

Reference	Designation	Manufacturer
12226-1150-00FR	SDR26 connector	3M


Hirose Connector Pinout		
Pin	Signal Name	Cable color
1	Power (6-24V)	Red/Purple/(Orange)
2	Power GND	Blue/Brown
3	Trigger OUT2	White
4	Trigger OUT1	Yellow
5	NC	
6	NC	
7	Reserved	
8	Power GND	Blue/Brown
9	Power (6-24V)	Red/Purple/(Orange)
10	Trigger IN/OUT (LVTTTL)	Green
11	Not connected	
12	Trigger GND	Black

# Mechanical ICD (SenS 1920 M-ST)



\*Products and specifications discussed herein are for evaluation and reference purposes only and are subject to change by NIT without notice.  
Products are only warranted by NIT to meet NIT's production data sheet specifications.

# Mechanical ICD - With Heatsinks (SenS 1920 M-ST)



\*Products and specifications discussed herein are for evaluation and reference purposes only and are subject to change by NIT without notice.  
 Products are only warranted by NIT to meet NIT's production data sheet specifications.

# Mechanical ICD (SenS 1920 L-ST)

Top view dimensions: 25, 58, 58, 25, 12,5, 32, 17,3, 52,8, 7,5

Bottom view dimensions: 16,3, 25

Side view dimensions: 25

Dimensions and specifications:

- 4 x  $\varnothing 2,5 \nabla 6,5$   
M3 - 6H  $\nabla 6$
- 8 x  $\varnothing 2,5 \nabla 6,5$   
M3 - 6H  $\nabla 6$
- $\varnothing 5,1 \nabla 6,5$   
1/4-20 UNC  $\nabla 6$
- $\varnothing 5 \nabla 6,5$   
M6 - 6H  $\nabla 6$

LSHM-130-06.0-X-DV-A-S

Item	Part	Quantity	Unit	Description	Material
1	ICD	1	PCB	ICD	PCB
2	ICD	1	PCB	ICD	PCB
3	ICD	1	PCB	ICD	PCB
4	ICD	1	PCB	ICD	PCB
5	ICD	1	PCB	ICD	PCB
6	ICD	1	PCB	ICD	PCB
7	ICD	1	PCB	ICD	PCB
8	ICD	1	PCB	ICD	PCB
9	ICD	1	PCB	ICD	PCB
10	ICD	1	PCB	ICD	PCB
11	ICD	1	PCB	ICD	PCB
12	ICD	1	PCB	ICD	PCB
13	ICD	1	PCB	ICD	PCB
14	ICD	1	PCB	ICD	PCB
15	ICD	1	PCB	ICD	PCB
16	ICD	1	PCB	ICD	PCB
17	ICD	1	PCB	ICD	PCB
18	ICD	1	PCB	ICD	PCB
19	ICD	1	PCB	ICD	PCB
20	ICD	1	PCB	ICD	PCB
21	ICD	1	PCB	ICD	PCB
22	ICD	1	PCB	ICD	PCB
23	ICD	1	PCB	ICD	PCB
24	ICD	1	PCB	ICD	PCB
25	ICD	1	PCB	ICD	PCB
26	ICD	1	PCB	ICD	PCB
27	ICD	1	PCB	ICD	PCB
28	ICD	1	PCB	ICD	PCB
29	ICD	1	PCB	ICD	PCB
30	ICD	1	PCB	ICD	PCB
31	ICD	1	PCB	ICD	PCB
32	ICD	1	PCB	ICD	PCB
33	ICD	1	PCB	ICD	PCB
34	ICD	1	PCB	ICD	PCB
35	ICD	1	PCB	ICD	PCB
36	ICD	1	PCB	ICD	PCB
37	ICD	1	PCB	ICD	PCB
38	ICD	1	PCB	ICD	PCB
39	ICD	1	PCB	ICD	PCB
40	ICD	1	PCB	ICD	PCB
41	ICD	1	PCB	ICD	PCB
42	ICD	1	PCB	ICD	PCB
43	ICD	1	PCB	ICD	PCB
44	ICD	1	PCB	ICD	PCB
45	ICD	1	PCB	ICD	PCB
46	ICD	1	PCB	ICD	PCB
47	ICD	1	PCB	ICD	PCB
48	ICD	1	PCB	ICD	PCB
49	ICD	1	PCB	ICD	PCB
50	ICD	1	PCB	ICD	PCB
51	ICD	1	PCB	ICD	PCB
52	ICD	1	PCB	ICD	PCB
53	ICD	1	PCB	ICD	PCB
54	ICD	1	PCB	ICD	PCB
55	ICD	1	PCB	ICD	PCB
56	ICD	1	PCB	ICD	PCB
57	ICD	1	PCB	ICD	PCB
58	ICD	1	PCB	ICD	PCB
59	ICD	1	PCB	ICD	PCB
60	ICD	1	PCB	ICD	PCB
61	ICD	1	PCB	ICD	PCB
62	ICD	1	PCB	ICD	PCB
63	ICD	1	PCB	ICD	PCB
64	ICD	1	PCB	ICD	PCB
65	ICD	1	PCB	ICD	PCB
66	ICD	1	PCB	ICD	PCB
67	ICD	1	PCB	ICD	PCB
68	ICD	1	PCB	ICD	PCB
69	ICD	1	PCB	ICD	PCB
70	ICD	1	PCB	ICD	PCB
71	ICD	1	PCB	ICD	PCB
72	ICD	1	PCB	ICD	PCB
73	ICD	1	PCB	ICD	PCB
74	ICD	1	PCB	ICD	PCB
75	ICD	1	PCB	ICD	PCB
76	ICD	1	PCB	ICD	PCB
77	ICD	1	PCB	ICD	PCB
78	ICD	1	PCB	ICD	PCB
79	ICD	1	PCB	ICD	PCB
80	ICD	1	PCB	ICD	PCB
81	ICD	1	PCB	ICD	PCB
82	ICD	1	PCB	ICD	PCB
83	ICD	1	PCB	ICD	PCB
84	ICD	1	PCB	ICD	PCB
85	ICD	1	PCB	ICD	PCB
86	ICD	1	PCB	ICD	PCB
87	ICD	1	PCB	ICD	PCB
88	ICD	1	PCB	ICD	PCB
89	ICD	1	PCB	ICD	PCB
90	ICD	1	PCB	ICD	PCB
91	ICD	1	PCB	ICD	PCB
92	ICD	1	PCB	ICD	PCB
93	ICD	1	PCB	ICD	PCB
94	ICD	1	PCB	ICD	PCB
95	ICD	1	PCB	ICD	PCB
96	ICD	1	PCB	ICD	PCB
97	ICD	1	PCB	ICD	PCB
98	ICD	1	PCB	ICD	PCB
99	ICD	1	PCB	ICD	PCB
100	ICD	1	PCB	ICD	PCB

LSHM-130-06.0-X-DV-A-S

LSHM-130-06.0-X-DV-A-S

Gen. Tol. : +/- 0.100000mm All dimensions are in mm  
 Surface Finishing: Sandblasting  
 Treatment: Surtec 650  
 Material: Aluminium 7075  
 Designer: VN  
 Date: 29/09/2022

A4

1-4 impasse de la noisette,  
 Bat D, 1er Etage,  
 FRANCE - 91370 Verrières le  
 buisson

Tel : +33 1 64 47 88 58  
 www.new-imaging-technologies.com

Information contained in this document is the property of NEW IMAGING TECHNOLOGIES and is communicated confidentially for a specific matter.  
 The receiver is in charge of this document and ensures that it will not be either copied or reproduced in all part, and that the content will not be disclosed in any way to anybody  
 except for its proper use.  
 The receiver is in charge of destroying any previous revision of this document in his possession.

Rev. Date	Creation Modification	Check	VN
A 29/09/2022		Check	Author

Doc. Ref. : SenS 1280L-ST

REV. SHEET  
 A 1/2

\*Products and specifications discussed herein are for evaluation and reference purposes only and are subject to change by NIT without notice.  
 Products are only warranted by NIT to meet NIT's production data sheet specifications.



NIT

1 Impasse de la noisette, Bat D- 1<sup>er</sup> étage, BP426

91370 Verrières Le Buisson Cedex, France

Tel +33(0) 1 64 47 88 58

[www.new-imaging-technologies.com](http://www.new-imaging-technologies.com)

[info@new-imaging-technologies.com](mailto:info@new-imaging-technologies.com)

**NIT, New Imaging Technologies and Native WDR, are trademarks of New Imaging Technologies.**



\*Products and specifications discussed herein are for evaluation and reference purposes only and are subject to change by NIT without notice.  
Products are only warranted by NIT to meet NIT's production data sheet specifications.